SWITCH /SWITCH LITE Mini Handheld Arcade Machine Specifications

Product Features:

1. Suitable for console: SWITCH / SWITCH LITE consoles.
2. Classic arcade button design, joystick control, provide players with better game control methods, increase game fun, especially suitable for fighting games..
3. Plug and play, no need to set.
4. Plug in the power supply to work, no power or battery.
5. Optional charging function. The consoles can be recharged through the power adapter, allowing the player to keep powering up during the game..
6. Beautiful design, cool shape, black / blue / red color matching.
7. Support TURBO continuous play function, subdue the enemy with one stroke.
8. HOME button design, one button return.
9. 13 function buttons, the keys are sensitive.
10. Small size, size 114*140*62mm and weight 200g, it is very convenient for daily use and travel.
11. SWITCH/SWITCH LITE transforms into the strongest desktop arcade, no need to use any small arcade, and an NS solves all your needs.
12. One machine is versatile and can be used as a base.

Product Parameters:

1. Colour:

Red/black HS-SM319/HS-SM319C

2.Controller parameters:

Product size: 114*140*60mm

Product weight: 0.200kg

Material: ABS

Product color: Upper cover (black) + lower cover (black) + decorative bar rocker body (blue / red) + button (black) color optional

Small button silk print: White A,B,X,Y

Note: This product does not contain power

3.Electrical parameters:

Compatible operating platform:	SWITCH /SWITCH LITE
Console connection interface:	TYPE C
Power interface:	TYPE C
Input voltage:	DC16V
Input current:	2.6A
Function key:	A，B，X，Y，L,R,ZL,ZR,+，-，T，HOME，L3

4. Packaging Parameters:

Single package weight: kg

Color box size: mm

Packing quantity: sets / box

Packing size:

Gross weight:

5. Information: Pictures, Function manual

6. Operating Guidelines

1). Mode and connection instructions

The TYPE-C interface on the console is connected to the TYPE-C interface of the Arcade . After the connection is successful, the indicator light is always on;

2). Turbo function

Press the one or several buttons (A/B/X/Y/L/R/ZL/ZR) and press the "TURBO" button to set the burst function. Press and hold the set burst action button again and press the "TURBO" button to clear the burst function of the button.

7. Console connection picture:

8. Product Pictures: